

2 Gallon Tank Assembly

(Pump Mounted)

Ensure all required hardware is there before starting the installation.

Tools Required

3/4" Drill Bit

3/4" Wrench

3/16" Hex Driver

8mm Hex Driver




Step 1 Locate the circle imprinted on the back right side of the tank and drill a $\frac{3}{4}$ " hole in the center of the circle. Be sure to remove all debris from the tank after drilling the hole. Next remove the low-level sensor nut, washer and grommet. Feed the wires through the lid and out the drilled hole. Finally slide the sealing grommet over the wires to seal the hole, install the washer and tighten the nut. Be sure the arrow on the sensor is facing down or it will not function correctly.




Step 2 On the back side of the tank there will be a bung needing a plug. Using one of the supplied plugs, apply the supplied thread sealer and tighten until snug.



Step 3 Turn the tank upside down exposing the feed ports and the mounting points for the pump. The pump IS directional so the feed fitting must go in the left bung. Using supplied sealer install the feed fitting and plug the remaining port. Using the supplied sealer install the two provided 90° fittings into the pump. (see picture for proper 90 degree fitting orientation)



Step 4 Install the supplied 4an line from the tanks outlet to the pumps inlet. Finally mount your tank in the desired location and enjoy your Snow Performance Water/Methanol System.



SNOW PERFORMANCE (the warrantor) hereby warrants its product under the following terms and conditions:

- Snow Performance Water / Methanol branded products are covered by a 1 year Limited Warranty against defects in workmanship and material. This warranty shall extend for a period of one year, commencing from the date of the original purchase.
- Snow Performance Fuel System branded products are covered by a Lifetime Limited Warranty against defects in workmanship and material.
- The warranty is specifically limited to the original purchaser of the products and is enforceable only by such original purchaser (proof of purchase is required). In the event of a defect in workmanship or material of the products, the warrantor will repair or replace the product at the election of the warrantor. The warranty shall not apply to labor charges, freight, material or other incidental expenses in connection with removal and/or replacement of such defective product on the consumer's vehicle. The warranty does not include electrical components and does not cover damage from standard wear and tear, modifications by the end-user, accidents, or when the product is used for something besides its intended purpose. The warranty does not include products that are not produced by the warrantor. The maximum liability of the warrantor in connection with this warranty shall not under any circumstances exceed the contract price of the product claimed to be defective.

Thanks for choosing
SNOW PERFORMANCE