



SNOW PERFORMANCE THROTTLE BODY INJECTION PLATE INSTALLATION

The Snow Performance Throttle Body Spacer makes nozzle installation a breeze with pre-tapped ports, eliminating the need to drill through your intake tube.

Installing the Throttle Body Plate

1. Locate the Battery of the vehicle and disconnect the Negative Battery Terminal.
2. Unplug any sensors and remove any vacuum lines attached to the throttle body and remove the throttle body from the vehicle. (You may need to take pictures for future reference).
3. Remove the bolts holding the throttle body to the intake manifold on the vehicle.
4. Remove the throttle body from the intake manifold, keeping the factory gasket/O-ring in place. (You may need to remove the air filter assembly.)
5. Install the throttle body plate between the intake manifold and throttle body.
6. Using the supplied bolts install the throttle body plate and intake assembly back onto the vehicle.
7. Reconnect any wire harnesses, vacuum lines, you had removed from the throttle body and intake assembly.
8. Check for any clearance issues and correct spacer/throttle body fitment and continue with the system install.
9. Reinstall the Negative Battery Terminal and your Snow Performance Injection Plate is now installed.

Note: The spacer has 2 ports to be used for nozzles OR a boost reference port. If only one nozzle is used a 1/8th NPT plug can be used to block the unused port.